

B302

AUTOMOTIVE ANTIFREEZE

This product provides superior corrosion protection while preventing winter freezing. In summer it acts as a coolant preventing summer boil-over. This product is silicone and silicate free and compatible for use in diesel and all other automobile engines.

NOTE: For maximum corrosion protection, antifreeze should be replaced annually.

DIRECTIONS: Always consult your Owner's Manual. Drain the system. If rusty or dirty, it should be cleaned. Examine all hoses, clamps and replace if needed. Fill system with soft or de-ionized water. Run engine with heater on high until warm. Thoroughly drain system again. Repeat until drained water is clear. Add automotive antifreeze using a desired ratio as mentioned below.

Freezing point of antifreeze-water mixtures:

% Antifreeze	% Water	Freezing Point
50	50	-37°C
60	40	-52°C
70	30	-64°C

COMMERCIAL USE ONLY

October 18, 2016



Intertek