

J444

WILD CHERRY LIQUID DISHWASH

This product is an effective liquid dish detergent with a fresh wild cherry scent that provides long lasting cleaning power for manual washing of dishes, pots and pans. It contains mild synthetic detergents which produces a rich long-lasting foam.

It is a non-phosphate biodegradable detergent that produces hygienically clean film-free dishes.

DIRECTIONS: The dilution ratio will vary with the cleaning application, amount of soil and water conditions. Use at a rate of 15 ml per 10 litres (1 oz per 5 gal) of water.

COMMERCIAL USE ONLY

2016-11-21



Intertek