

J462

## K-20 OVEN CLEANER

This product is a highly alkaline degreaser with sequestering agents and surfactants. It is designed for heavy duty cleaning of kitchen canopies, grills, deep fryers, hood screens and ovens.

**DIRECTIONS:** For cleaning ovens, fryers and grills, preheat before cleaning to 81°C (180°F). Then shut off before applying the product.

**Commercial Ovens:** Use at full strength. Using a brush, apply cleaner directly to walls and racks. Allow 5 - 15 minutes contact time. Stubborn areas may need some scrubbing. Rinse well with potable water. Wipe dry.

**Grills, Hood Screens, Fume Hoods, Pizza Ovens:** Dilute 1 part with 1 part water and apply using a brush or cloth. Allow 5 - 10 minutes contact time. Wipe clean using a wet cloth or sponge. Rinse well with potable water and wipe dry.

**Deep Fryers:** Remove excess grease. Fill up to 10 cm (4 in) from top with cold water. Add 1 part to 40 parts of water. Boil the solution for 30 minutes. Drain and flush off using hot water. Rinse well with potable water. Wipe dry.

**Kitchen Canopy Flush Systems:** Use at full strength.

**CAUTION:** Keep out of reach of children. This product contains caustic. Avoid prolonged and repeated contact with aluminum.

**FOR COMMERCIAL USE**

2016-11-23



Intertek