

G680

POWER FLUSH

This product is an alkaline degreaser with sequestering agents, surfactants and water soluble solvents for heavy duty cleaning of kitchen canopies, grills, deep fryers, hood screens and ovens.

DIRECTIONS: For cleaning ovens, fryers and grills, preheat before cleaning to 81°C (180°F). Then shut off before applying the product.

Commercial Ovens: Use at full strength. Using a brush apply cleaner directly to walls and racks. Allow 5-15 minutes contact time. Stubborn areas may need some scrubbing. Rinse well with potable water. Wipe dry.

Grills, Hood Screens, Fume Hoods, Pizza Ovens:

Dilute 1 part with 1 part water and apply using a brush or cloth. Allow 5-10 minutes contact time. Wipe clean using a wet cloth or sponge. Rinse well with potable water and wipe dry.

Kitchen Canopy Flush Systems: Use at full strength.

COMMERCIAL USE ONLY

October 24, 2016



Intertek

TECHNICAL DATA SHEET